




Instruction Manual




1. Place the frame in front of you with the light connectors facing away from you.



2. Open the frame slightly by pulling the hinges outwards.




3. Place your hands on the bars as shown in the picture.




4. Gently lift up the frame while flipping it over, the pop-up frame will unfold itself.



5. Check if all the clips are facing the opposite parts and close them to lock the frame.



6. Close the attached bars in the corners.



7. Slide in the aluminium bars from the side, on both the front and the backside of the frame.



8. Place the frame on the ground, the adjustable feet mark the bottom side of the frame.



9. Attach the fabric by pushing the silicone edges in de grooves.




10. Start in the corners of the frame, to divide the tension.



11. Work your way around the frame until all silicone edges are attached.



12. Lift the frame up again, the Pop Up Impress is now ready to use.



13. **Optional:** for double-sided use, add the extra bars on the top and bottom of the backside.



14. **Optional:** attach the feet for more stability, by sliding them over the 2 adjustable feet.